



**BORNIER X DE RACCORDEMENT**

V/J	T	V/J
Bleu Ci.	N	BLEU
Brun	L1	GRIS
Noir	L2	GRIS
Gris	L3	GRIS

ALIMENTATION TRI + N + T

PHASE 230V	1	GRIS
CONTACT 21	2	GRIS
PHASE 230V	3	GRIS
CONTACT 22	4	GRIS
PHASE 230V	5	GRIS
PHASE 230V	6	GRIS
PHASE 230V	7	GRIS
SIGNAL	8	GRIS
SIGNAL	9	GRIS

ALIM. 230VCA  
 PRESSOSTAT ELECTROVANNE  
 PRESSOSTAT  
 VENTILATION EVAP.  
 VENTIL. COND.  
 RESISTANCE DE CARTER  
 CONTACT DE PORTE  
 CONTACT DE PORTE

RESISTANCE DE CARTER  
 VENTILATION COND.  
 NEUTRE 230V  
 NEUTRE 230V  
 Bleu  
 Bleu

Bleu	N	Bleu
N	N	N
N	N	N

ALIM. 230VCA  
 ELECTROVANNE  
 VENTILATION EVAP.